



Procedure For Use Of

Bouncy Castle

1. The Bouncy Castle **MUST NOT BE USED OUTDOORS**
2. The Bouncy Castle **must** be secured to the floor using the weight bags.
3. Always site the Bouncy Castle well clear of obstructions including overhead obstructions
4. Soft gym mats must be used at the access and dismounting area of the Bouncy Castle.
5. **MAXIMUM NUMBER OF CHILDREN ON THE BOUNCY CASTLE AT ANY ONE TIME IS 12. THIS MUST BE ENFORCED AT ALL TIMES.**
6. No sharp objects (jewellery, buckles, spectacles etc.) to be allowed on the Bouncy Castle.
7. No one is to be allowed on the Bouncy Castle during the inflation/deflation operation.
8. No inappropriate use of the Bouncy Castle allowed - e.g. pushing, somersaulting, climbing sides etc.
9. A responsible (trained) adult must supervise the use of the Bouncy Castle at all times.
10. Children under the age of 2 must not be allowed to use the Bouncy Castle.
11. A rota system must be used to ensure that 'mixed age' groups do not use the Bouncy Castle at the same time. (age groups allowed: 2 to 5 years and 6 to 11 years)
12. No one over the age of 11 years is allowed to use the Bouncy Castle.